

# Wiser Temperature/Humidity Sensor

## Device user guide

Information about features and functionality of the devices

10/2022

# Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

---

# Table of Contents

Safety information .....	4
Wiser Temperature/Humidity Sensor .....	5
For your safety .....	5
About the device .....	6
Installing the device .....	6
Pairing the device .....	7
Configuring the device .....	9
Renaming the device .....	9
Changing the device location .....	9
Using the device .....	10
Checking the device history .....	10
Identifying the device .....	11
Creating an automation .....	12
Removing the device .....	18
Resetting the device .....	19
Replacing the battery .....	21
LED indications .....	21
Troubleshooting .....	22
Technical Data .....	22

# Safety information

## Important information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that accompany this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

**Failure to follow these instructions will result in death or serious injury.**

### **WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

### **CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

### **NOTICE**

NOTICE is used to address practices not related to physical injury.

## Wiser Temperature/Humidity Sensor



CCT593012

### For your safety

<b><i>NOTICE</i></b>
<b>EQUIPMENT DAMAGE</b> Do not install the sensor in a place where there is strong sunlight or wind (for example, close to the ventilation). <b>Failure to follow these instructions can result in equipment damage.</b>

## About the device

The Wiser Temperature/Humidity sensor (hereinafter referred to as **sensor**) combines two sensors in one unit. The sensor measures temperature and humidity in the environment where the sensor is installed. When the sensor is connected to the **Wiser Hub**, it reports the temperature and humidity data to the **Wiser Hub**.


The sensor triggers other Wiser devices (such as turning on an air conditioner if the temperature is high or turning on an exhaust fan if the humidity is high) through automation.

### Features of the sensor:

- Detect temperature and humidity in the environment and send the information to the **Wiser Hub**.
- Send the battery level and offline device status information to the **Wiser Hub**.

## Operating elements

- A. Status LED
- B. Function key




## Installing the device

Refer to the installation instruction supplied with this product.




## Pairing the device

Using the Wiser Home app, you can pair your sensor with the **Wiser Hub** to access and control the sensor.  
To pair the sensor:

1. On the Home page, tap .
2. Tap **Devices** >  > **Climate**.
3. Tap **Temperature/Humidity Sensor** > **Next**.  
The next screen shows the sensor joining process.




4. Short press the function key 3 times (< 0,5 s).  
The LED blinks amber.




5. Wait for a few seconds until the sensor LED turns green.

**TIP:** The stable green LED on the sensor shows that it is successfully connected to the **Wiser Hub**.



You will see **Device joined** at the bottom of the screen once the sensor has been successfully connected to the **Wiser Hub**.



6. Ensure that the first battery cover is securely fastened, then install the sensor on the baseplate. For more information, refer to the [installation instruction](#).
7. Tap **Next** to enter the sensor name.
8. Tap **Next** to assign sensor location and then tap **Submit**.

**TIP:** You can find the paired sensor name and its location on the **All** or **Room** tab on the Home page.


# Configuring the device

## Renaming the device

Using the Wiser Home app, you can rename the sensor.  
To rename the sensor:

1. On the Home page, tap .
2. Tap **Devices > Temperature/Humidity Sensor > Device Name (A)**.

**TIP:** Additionally, you can rename the sensor by tapping on the Home page **Temperature/Humidity Sensor > Device settings > Device Name (A)**.




## Changing the device location

Using the Wiser Home app, you can change the sensor location.  
To change the sensor location:

1. On the Home page, tap .
2. Tap **Devices > Temperature/Humidity Sensor > Location (A)** to assign the sensor in your existing room or a new room (B).

**TIP:** Additionally, you can change the sensor location by tapping on the Home page **Temperature/Humidity Sensor > Device settings > Location (A)**.




## Using the device

The Control Panel of the sensor allows you to view the real-time temperature and humidity values.

On the **Home** page, tap **All > Temperature/Humidity Sensor** to access the control panel.

On the sensor control panel page, you can see the following:

- The current temperature value (A)
- The current humidity value (B)
- History (C)
- Device settings (D)



## Checking the device history

Using the Wiser Home app, you can view the sensor's history which displays room temperature and humidity values recorded as an event. The sensor records each event and stores it in the cloud.

**NOTE:** If the cloud connection is lost, the sensor's history page will not display the temperature and humidity values.

To view the sensor history:

1. On the Home page, tap **All > Temperature/Humidity Sensor**.
2. On the device control panel page, tap **History**.

History	
TODAY	
09:42:42	53% Humidity
17:21:35	62% Humidity
YESTERDAY	
11:42:42	53% Humidity
20TH DECEMBER 2021	
06:42:42	66% Humidity
19TH DECEMBER 2021	
23:42:42	44% Humidity

## Identifying the device

Using the Wiser Home app, you can identify the sensor from the other available devices in the room.

To identify the sensor:


1. On the Home page, tap .

**NOTE:** Please wake up the sensor (press the function key).

2. Tap **Devices > Temperature/Humidity Sensor > Identify (A)**.

**TIP:** Additionally, you can identify the sensor by tapping on the Home page **Temperature/Humidity Sensor > Device settings > Identify (A)**.

**NOTE:** The sensor LED blinks to identify the sensor and it continues blinking green until you tap **OK**.




## Creating an automation


An automation allows you to group multiple actions that are usually done together, triggered automatically or at scheduled times. By using the Wiser app, you can create automations based on your needs.

To create an automation:

1. On the **Home** page, tap .
2. Go to **Automation** >  to create an automation.  
**NOTE:** Max. 10 automations can be added.
3. Tap **If (A)** and select any of the following conditions (B):
  - **All conditions:** This triggers an action only when all conditions are met.
  - **Any condition:** This triggers an action when at least one condition is met.




4. Tap **Add conditions** and select any of the following (C):
  - **Device status change:** Select a device to enable automation.
  - **Away Mode:** Enable/Disable away mode to trigger an action.  
**TIP:** Away mode can also be used as a trigger to turn off the lights, dimmer or closing the shutter etc. For more information refer to [Away mode](#).



5. Tap **Device status change** > **Temperature/Humidity Sensor**, Select any of the following:
  - Temperature
  - Humidity


6. Tap **Temperature**, Set the temperature using sliding bar (D) and select the condition (E) (less than / more than), then tap **Set**.



**NOTE:**

- Max. 10 conditions can be added.
- To remove an added condition, swipe left and tap .


7. To set a specific time for your automation, tap **When > Add time** and select any of the following (F):
- **Specific time of the day: Sunrise, Sunset, Custom.**
  - **Period of time: Daytime, Night time, Custom.**




**NOTE:**

- Max. 10 entries can be added
- To remove a specific time, swipe left and tap .


8. To add an action, tap **Then** > **Add an action** and select any of the following (G):
- **Control a device:** Select a devices that you want to trigger.
  - **Send notification:** Turn on the notification for the automation.
  - **Activate a moment:** Select the moment that you want to trigger.



9. Tap **Control a device** > **Heating** and select any of the following (H):
- **Boost:** Set the duration to increase the temperature by 2° C.
  - **Setpoint:** Set the desired temperature.



10. Tap **Setpoint**, set the required temperature using sliding bar (I), then tap **Set**.




**NOTE:**

- Max. 10 actions can be added.
- To remove an action, swipe it left on the action and then tap .

11. Enter the automation name (J).


You can choose the cover image that represents your automation by tapping



12. Tap **Save**.

Once the automation is saved, it is visible on the **Automation** tab.

Using the  (K) you can enable and disable the automation.



## Example of an automation

This demonstration shows you how to make the automations that the heater switches on at 22 °C when the room temperature is 17 °C or lower and switches off when the room temperature is 25 °C or higher.

**NOTE:** It is mandatory to create two automations. First, switch on the heater at 22 °C when the room temperature is at 17 °C or lower. Second, switch off the heater when the room temperature is at 25 °C or above.


**The room heater will not turn off automatically until you create another automation.**

1. On the Home page, tap .


2. Tap **Automations** >  to create an automation.

– **First Automation**


- Tap **Add conditions** > **Device status change** and find your sensor from the list of devices.  
**NOTE:** Additionally, you can also locate the sensor from the available rooms.
- Tap **Temperature/Humidity Sensor** > **Temperature** > **less than** and adjust the temperature at 17 °C on the sliding bar and tap **Set** (A).



- To add an action, tap **Then** > **Add an Action** > **Control a device** and go to the room tab where heater is installed.
- Tap **Heating** > **Setpoint** and adjust the sliding bar to switch on at 22 °C and tap **Set** (B).




- You can choose the cover image that represents your automation by tapping  (C).
- Enter the name of the automation (D) and tap **Save** (E).



**NOTE:** Once the automation is saved, it is visible on the Automation tab. You can tap the toggle switch on the automation to enable it.

#### – Second Automation

- Tap **Add conditions** > **Device status change** and find your sensor from the list of devices.
- Tap **Temperature/Humidity Sensor** > **Temperature** > **more than** and adjust the sliding bar at 25 °C and tap **Set** (F).



- To add an action, tap **Then** > **Add an Action** > **Control a device** and go to the room tab where heater is installed.
- Tap **Heating** > **Setpoint** and adjust the sliding bar to switch off and tap **Set** (G).




- Enter the name of the automation and tap **Save**.  
Once the automation is saved, it is visible on the Automation tab. You can tap the toggle switch on the automation to enable it.

## Editing an automation

To edit an automation:

1. On the **Home** page, tap .
2. Go to **Automation**, tap the automation you want to edit.
3. On the **Edit automation** page, you can:
  - Change the icon.
  - Rename the automation.
  - Change/Delete the condition or action.

- Remove the Condition or Action by swiping it to the left and tapping the **bin** (A).




- Add a new condition or action and then tap **Save**.

## Deleting an automation

To delete an automation:

- On the **Home** page, tap .
- Go to **Automation**, tap the automation you want to delete .
- On the Edit automation page, tap **Delete Automation** (A) and tap **Ok**.



## Removing the device


Using the Wiser Home app, you can remove the sensor from the Wiser system. To remove the sensor:

- On the Home page, tap .

**NOTE:** Please wake up the sensor (press the function key).

2. Tap **Devices > Temperature/Humidity Sensor > Delete (A)**.

**TIP:** Additionally, you can remove the Sensor from the Wiser system by tapping on the Home page **Temperature/Humidity Sensor > Device settings > Delete (A)**.



3. Read the confirmation message and tap **Ok** to remove the sensor from Wiser system on the next screen.


**NOTE:**

- Removing the sensor will reset the sensor. After resetting, the LED blinks amber indicating that the sensor is ready for pairing.
- If there is a problem while pairing or resetting the sensor, refer to [Resetting the device](#), page 19.

## Resetting the device

You can reset the sensor to factory default manually.  
To reset the sensor:


1. Remove the sensor from the base plate by sliding it upwards.




- Short-press the function key 3 times ( $<0.5$  s) and then long-press the function key once ( $>10$  s), the LED blinks red after 10 s, and then release the function key.

Upon successful reset of the sensor, the LED stops blinking. Then, the sensor restarts and blinks green for a few seconds.

**NOTE:** After reset, the LED turns off to save the battery.



$3 \times < 0,5 \text{ s} + 1 \times 10 \text{ s}$




## Replacing the battery

To replace the batteries:

1. Remove the sensor from the base plate by sliding it upwards.
2. Unscrew the battery cover using a screwdriver.
3. Replace the battery with the proper polarity.
4. Re-install the battery cover and tighten the screw using a screwdriver.  
The LED blinks green seven times and then stops blinking.
5. Install the sensor on the base plate by sliding it down.

**NOTE:** Dispose used batteries, as per statutory regulations.



## LED indications

### Pairing

User Action	LED Indication	Status
Press the function key 3 times	LED blinks amber, once per second. 	Pairing mode is active for 30 seconds. When pairing is completed, LED glows green for some time before turning Off. 

### Resetting

User Action	LED Indication	Status
Press the function key 3 times and long press once for > 10 s.	After 10 s, the LED starts blinking red. 	The sensor is in reset mode. It is reset to the factory settings after 10 seconds. The sensor then restarts, and the LED starts blinking green before turning Off. 

### Battery level

LED Indication	Status
LED blinks amber once per minute. 	The battery is low (< 10%), replace the battery, page 21. <b>NOTE:</b> A notification pop-up will appear on the app.

### Identifying the device

LED Indication	Status
LED blinks green. 	Sensor is connected to the <b>Wiser Hub</b> . <b>NOTE:</b> This function is initiated from the app to identify the sensor.

## Troubleshooting

Symptom	Possible cause	Solution
The sensor triggers the automation/schedule, but does not show the status on the app.	The sensor may be undergoing an over-the-air (OTA) firmware update.	Wait for the firmware update to complete and then check that the sensor is reporting status. <b>NOTE:</b> The firmware update runs in the background.
LED blinks amber.	The sensor battery is low or drained.	Replace the battery in the device, page 21 <b>NOTE:</b> A notification pop-up will appear on the app.

## Technical Data

Battery	3 VDC, CR2450
Battery life	Up to 5 years (may vary based on the usage, frequency of firmware update and environment)
Nominal power	≤90 mW
IP rating	IP20
Operating frequency	2405 – 2480 MHz
Max. radio-frequency power transmitted	≤7 dBm
Operating temperature	-10 °C to 50 °C
Temperature accuracy	±1.5 °C
Temperature resolution	0.1 °C
Relative humidity	10 % to 95 %
Humidity accuracy	±5 %
Dimensions (H x W x D)	45 x 45 x 17.2 mm
Communication protocol	Zigbee 3.0 certified

# Compliance

## Compliance information for Green Premium products

Find and download comprehensive information about Green Premium products, including RoHS compliance and REACH declarations as well as Product Environmental Profile (PEP) and End-of-Life instructions (EOLI).

### General information about Green Premium products

Click the link below to read about Schneider Electric's Green Premium product strategy.

<https://www.schneider-electric.com/en/work/support/green-premium/>

### Find compliance information for a Green Premium product

Click the link below to search for a product's compliance information (RoHS, REACH, PEP and EOLI).

**NOTE:** You will need the product reference number or product range to perform the search.

<https://www.reach.schneider-electric.com/CheckProduct.aspx?cskey=ot7n66yt63o1xblflyfj>

## Trademarks

This guide makes reference to system and brand names that are trademarks of their relevant owners.

- Zigbee® is a registered trademark of the Connectivity Standards Alliance.
- Apple® and App Store® are brand names or registered trademarks of Apple Inc.
- Google Play™ Store and Android™ are brand names or registered trademarks of Google Inc.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- Wiser™ is a trademark and the property of Schneider Electric, its subsidiaries and affiliated companies.

Other brands and registered trademarks are the property of their respective owners.

Schneider Electric  
35 rue Joseph Monier  
92500 Rueil Malmaison  
France

+ 33 (0) 1 41 29 70 00

[www.se.com](http://www.se.com)

As standards, specifications, and design change from time to time,  
please ask for confirmation of the information given in this publication.

© 2022 – Schneider Electric. All rights reserved.

DUG\_Temperature/Humidity Sensor\_WH-01